


Do not lay out "perimeter control" silt fence along property lines; all sediment laden runoff will concentrate and overwhelm the system.

The distance of sheet flow to the silt fence should not exceed 100 feet.


Land Slope to Flow Length	
Land Slope	Maximum Sheet Flow Distance to Fence
3% - 5%	100-ft.
5% - 10%	75-ft.
10% - 20%	50-ft.
20% - 50%	25-ft.

### Silt Fence Design Examples

*Placement on One Slope*



*Placement on Two Slopes*



*Placement for Perimeter Control*

