



Silt Fence Design Examples




Placement on One Slope



Placement on Two Slopes



Placement for Perimeter Control



- **Stabilized construction exit:** Inspect every 7 calendar days and after a storm event of 0.5 inch or greater. If vehicles passing through stabilized exit continue to track sediment onto adjacent roadways, replenish stone or replace it completely. Immediately sweep any sediment on roadway.
- **Floating turbidity curtain:** Inspect daily and repair if necessary. Remove any floating construction or natural debris immediately to prevent damage. If necessary, remove sediment deposited behind the curtain by hand prior to removal. Remove curtain by carefully